


# Blue LED Glass Kettle

KA-KTL-02



## Contents


Introduction	1
Parts Included	1
Important Safeguards	2
Using the Appliance	2
Cleaning	3
Technical Specifications	3
Environmental Info and Support	3

## Introduction

Congratulations on your new purchase and thank you for choosing Dihl.

Your new Dihl kettle allows you to make a hot drink quickly. Read this user manual carefully before you use the appliance and save it for future reference.

# PARTS INCLUDED



1. On/off switch
2. Water Tank Lid
3. Handle
4. Water Level
5. Base
6. Spout

# IMPORTANT SAFEGUARDS

## Caution

1. Read all instructions carefully before use.
2. Before first use, check to ensure the voltage indicated on the unit corresponds to the voltage of your home.
3. Do not operate the unit if the water is below the minimum level as this will cause damage to the heating element.
4. Do not let the cord hang over the edge of a table or counter, and keep away from hot surfaces or naked flames.
5. Do not put the appliance in the refrigerator.
6. Do not lean the appliance or operate it upside down.
7. For indoor, domestic use only.
8. This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
9. The unit is not intended to be operated by means of an external timer.
10. Keep away from children. Do not allow children to play with the unit.
11. To prevent electric shock or other injury, never immerse the appliance in water or any other liquid, nor rinse it under the tap.
12. Do not touch the hot surface or water spout when in use.
13. Do not block the steam outlet or open the water tank lid while the appliance is in use.
14. Do not use the appliance to heat anything other than water.
15. Do not fill the water jug above the maximum level.

# USING THE APPLIANCE

## Preparing for use

1. Place on a flat surface.
2. Plug the unit into the mains and ensure it has power.
3. Clean thoroughly before first use.
4. Fill the water tank and boil the water several times before first use.
5. Ensure that the water level does not go above the 'MAX' level.
6. Press the 'ON' button to dispense water.
7. Always wait for the water to stop boiling before lifting the kettle.

# CLEANING

1. Always switch off and unplug your appliance and allow it to completely cool before cleaning.
2. Do not immerse the unit in any liquid.
3. Wipe the outside of the appliance with a clean, damp cloth.
4. Clean the appliance with hot soapy water and a non-abrasive sponge.
5. To maintain performance, descale the appliance monthly. To do this, add some detergent to hot water and operate the unit at least three times. Rinse thoroughly with clean water before using again.

# TECHNICAL SPECIFICATIONS

Model	KA-KTL-02
Product Name	Glass Kettle with blue LED
Voltage	240 V
Rated Power	1800 W
Capacity	1.8 L

# ENVIRONMENTAL INFO AND SUPPORT

## Storage

1. Unplug the appliance and let it cool down.
2. Make sure all parts are clean and dry.

## Thermostat Reset

There may be occasions when the built-in thermostat cuts power to the device due to abnormal operating conditions.

If you discover that the device is no longer boiling water on demand, try pressing the reset button located behind where the water tank sits.

## Environment

Do not throw away the appliance with the normal household waste at the end of its life; hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

## Support

If you need more information or if you have a problem, please contact Dihl at [enquiries@dihl.co.uk](mailto:enquiries@dihl.co.uk). If you have purchased your item from another retailer, please contact them directly.

To view our entire product range, visit

[www.dihl.co.uk](http://www.dihl.co.uk)



**value**

quality

**no** compromise











